

interbois

Interior finishing. Elevated.

Installation guide

2D Barnwood

Working environment preparation

Wall covering installation should be the last step of a construction or renovation. First allow the wood to acclimatize to the air and the ambient temperature for at least 72 hours prior to installation.

Surface preparation

Please note that the wall covering will not correct any apparent or pronounced defects of the wall. It is therefore essential to make sure the wall or surface you are covering is in good condition prior to starting installation. Even out the surface by eliminating any remaining glue, nails, or any other material that could interfere with your installation.

Installation

Make sure you have good natural lighting before starting the project. The first row of boards must be perfectly level. Find out in advance if the installation will require moldings. If so, make sure to factor in the required space. We recommend measuring carefully to ensure the boards cut lengthwise line up with your starting line.

Before you begin

Before installing the product, the installer and/or owner must make sure that the wall complies with the conditions specified in this document. The installer and the buyer are responsible for inspecting the products before installing them. The product may have lighter vertical marks. These are marks left by the drying of the wood and they are part of the products. If the installer notices imperfections in product manufacturing or finishing and cannot install the product in an inconspicuous location or eliminate the imperfections, he or she should not install it. If there are damaged boards, put them aside and use them for cuts. Five percent imperfection is considered acceptable for each box. This percentage does not include the cutting loss mentioned above. Once the product is installed, it is considered to have been accepted by the installer and/or the owner, even if he/she was not present during installation. Customers must make sure the product purchased is suitable for the desired installation. Proper board selection and layout will ensure an attractive final result. Now is the time to coordinate variations in color, length, and thickness according to the wood species. This will help you visualize the final result of your project.

Installation steps

Step 1

Draw horizontal lines at 1/4" (0.635 cm) and 1/2" (1.27 cm) from the floor. Make sure it is properly aligned with the horizontal line.


Step 2

On the back of the first board, run a bead of PL construction adhesive 1/2" (1.27 cm) from all four edges of the board.

The material you need

8518 | 2D Barnwood

9/16" and 13/16" x 5-5/8" x 2' to 5'



► Coverage: 16.94 sq ft

Additional information

- Outdoor installation: No
- Specie: Eastern white knotty pine
- Finish: Stainless white, copper
- Anticipate 10% cutting loss when purchasing materials

Outils nécessaires

- PL construction adhesive
- Caulking gun
- 18 gauge finishing nails
- Finishing nailer
- Measuring tape
- Level
- Miter saw
- Saw bench

Step 3

Secure the board by using the rabbet side down using on 18 gauge finishing nail.

Step 4

Arrange the pieces by repeating steps 2 and 3. After each row, check if the board is leveled.

Please note

Wood is a living material that expands and contracts depending on the ambient temperature. A 1/6" space may be visible between pieces during dry weather.

To find out about the WARRANTY offered on the product, including particularities and warnings, visit: interbois.ca.

