



CLASSIC CASINGS

TOOLS REQUIRED

- Erasable pencil or masking tape
- Finishing nails, 18 gauge
- Finishing nailer
- Tape measure
- Level
- Mitre saw
- Wood filler
- Spring loaded-punch
- Caulking
- Caulking gun

MATERIAL REQUIRED

1925 | CHAIR RAIL MOULDING

- Thickness: 5/8"
- Width: 1-3/4"
- Length: 96"

ADDITIONAL INFORMATION

- Exterior installation: No
- Type: MDF with white primer
- When buying your material, allow about a 10% loss for cuts.

RECOMMENDATIONS

It is strongly recommended that you take the measurements of your wall before beginning in order to adjust your plans and make the calculations necessary to complete your project. You can print this guide and make it your personalized plan, based on your space, so you can determine the quantity as well as the width of your geometric patterns.

TIP


Use an erasable pencil or masking tape to mark the location of the mouldings directly on your wall. If the dimensions of the geometric patterns do not provide the desired effect, adjust your plans. It is also recommended to paint the background of your wall in your desired colour before you begin to create the geometric patterns. Once the mouldings are installed, they can be painted to harmonize your project.



INSTALLATION STEPS


STEP 1:

Measure the width and height of the wall. Divide the width according to the number of sections you want to have in order to locate where the vertical mouldings (A) will be placed. For this type of decorative wall, we suggest that you leave 6" at each end of the wall (B), 6" between each box (C) and 6" between your baseboard and your ceiling (D). We also suggest that you make a sketch of your wall to determine the different dimensions of your boxes and thus ensure you have the exact measurements.




STEP 2:

To install the first vertical moulding (A) (from the left), you must remove 24" from it according to the height measurement of your wall. Cut the piece with an interior angle of 45-degrees at the two ends, then fasten the first moulding (A) with the finishing nailer, centered in the height of your wall. Make sure the moulding is level. Repeat this step for the second right vertical moulding (B) of your casing. Repeat the same for the following boxes.



STEP 3:

Now cut the 4 mouldings (C) from the bottom of the 6" long box. Moulding (C1) on the left side will be cut with an interior angle of 45-degrees for the left end, and cut with an exterior angle of 45-degrees for the right end. Moulding (C2) on the left side will be cut with an outside angle of 45-degrees for the upper end and cut with an inside angle of 45-degrees for the lower end. Repeat the same for the right side, but reverse the cuts. Make sure the mouldings are level. Repeat the same for the top of the casing. Repeat the same for the remaining casings.



STEP 4:

Now cut the casing bottom moulding (D) with a 45-degree inside angle at both ends. Determine the required length by measuring the space between the mouldings (C2) and fasten to the wall. Make sure the moulding is level. Repeat the same for the top of the casing. Repeat the same for the remaining casings. Use wood filler and caulking to conceal imperfections. Let dry, lightly sand and paint the mouldings the same colour as the wall.

