



MID-CENTURY BAGUETTES

TOOLS REQUIRED

- Erasable pencil or masking tape
- Finishing nails, 18 gauge
- Finishing nailer
- Tape measure
- Level
- Mitre saw
- Wood filler
- Spring loaded-punch
- Caulking
- Caulking gun

MATERIAL REQUIRED

1565 | SQUARE

- Thickness: 1-1/16"
- Width: 1-1/16"
- Length: 96"

ADDITIONAL INFORMATION

- Exterior installation: No
- Type: MDF with white primer , jointed pine or select pine
- When buying your material, allow about a 10% loss for cuts.

RECOMMENDATIONS

It is strongly recommended that you take the measurements of your wall before beginning in order to adjust your plans and make the calculations necessary to complete your project. You can print this guide and make it your personalized plan, based on your space, so you can determine the quantity as well as the width of your geometric patterns.

TIP

Use an erasable pencil or masking tape to mark the location of the mouldings directly on your wall. If the dimensions of the geometric patterns do not provide the desired effect, adjust your plans. It is also recommended to paint the background of your wall in your desired colour before you begin to create the geometric patterns. Once the mouldings are installed, they can be painted to harmonize your project.




INSTALLATION STEPS

STEP 1:

Measure the length of the wall to determine the number of vertical mouldings (A) you will have to cut. We recommend that you leave $2\text{-}1/16''$ minimum between the vertical mouldings (A). So from the left of your wall, the first vertical moulding (A) will be attached with a $2\text{-}1/16''$ indent and the last vertical moulding (A) should have the same $2\text{-}1/16''$ indent to the right of the wall. For example, for a wall 10 feet long, you would have 38 vertical mouldings (A), considering that the vertical moulding (A) is $1\text{-}1/16''$ wide, with a space of $2\text{-}1/16''$ between them.

Measure the height of the wall from the top of your baseboard to the ceiling to determine the length of the vertical mouldings (A). Fasten the vertical mouldings (A) with the finishing nailer. Make sure the mouldings are level.



STEP 2:

For the vertical mouldings (B) that will be installed between the vertical mouldings (A). We suggest you cut them to half the total height of the wall. To install the vertical mouldings (B), take two scrap pieces of $1/2''$ wide wood to use as spacers (C) on each side of the vertical mouldings (B), between the vertical mouldings (A). This is to make sure the vertical mouldings (B) are centered between the vertical mouldings (A). Fasten the vertical mouldings (B) with the finishing nailer. Make sure the mouldings are level. Use wood filler and caulking to conceal imperfections. Let dry, lightly sand and paint the mouldings the same colour as the wall.

