



# RIPPLED CASINGS

## TOOLS REQUIRED

- Erasable pencil or masking tape
- Finishing nails, 18 gauge
- Finishing nailer
- Tape measure
- Level
- Mitre saw
- Wood filler
- Spring loaded-punch
- Caulking
- Caulking gun

## MATERIAL REQUIRED

### 8046 | DAME-S

- Thickness: 3/4"
- Width: 6-1/6"
- Length: 96"

### 0851 | WINDOW SILL MOULDING

- Thickness: 1"
- Width: 1-1/2"
- Length: 96"

## ADDITIONAL INFORMATION

- Exterior installation: No
- Type: MDF with white primer
- When buying your material, allow about a 10% loss for cuts.

## RECOMMENDATIONS

It is strongly recommended that you take the measurements of your wall before beginning in order to adjust your plans and make the calculations necessary to complete your project. You can print this guide and make it your personalized plan, based on your space, so you can determine the quantity as well as the width of your geometric patterns.

## TIP


Use an erasable pencil or masking tape to mark the location of the mouldings directly on your wall. If the dimensions of the geometric patterns do not provide the desired effect, adjust your plans. It is also recommended to paint the background of your wall in your desired colour before you begin to create the geometric patterns. Once the mouldings are installed, they can be painted to harmonize your project.



# INSTALLATION STEPS


## STEP 1:

Measure the length and height of the wall and divide it according to the number of sections you want to have. For this type of decorative wall, we suggest the following plan with the distances to leave between the sections. We recommend that you leave 7" on the left and right side of the wall (A). Leave 8" between the horizontal casings (B). Leave 6" between the vertical casings (C). And leave 7" above the baseboard and the top of the wall (D). We suggest that you make a sketch of your wall to determine the different dimensions of your casings and thus know the exact measurements.



## STEP 2:

For the first boxes (E) and (F), measure their height and length. It is necessary to plan the installation of mouldings 0851 (G) that will surround wall panel 8046 (H). So you must remove 2" from the measurement. For example, if you have a 48" high casing, the 8046 wall panel will have to be cut at 46". Do the same for the length of the casing. Fasten the 8046 (H) wall panel with the finishing nailer. Make sure you are level. Repeat these steps for the other casings.



## STEP 3:

Measure the length of the 0851 (G) mouldings that will be installed around the 8046 (H) casings. Measure and cut each piece to these measurements with a 45-degree inside angle on both ends. Fasten the moulding with the finishing nailer. Repeat this same step for all the contour mouldings of each of the casings.

